

# ***FiD 2.5" ATA series Installation Guide***

## **1. Pre-inspection**

### **1.1 Package**

The FiD is packed with the following accessory and components:

- 1pcs of FiD 2.5" ATA flash disk
- 1pcs of installation guide

If any listed item lost, please contact the dealer.

### **1.2 Unpacking the IFD**

Avoid any damage during the unpacking process, please ensure the FiD against the environment might cause malfunction, such as electrostatic, electromagnetic wave, water or flame.

- Scrutinize the outward appearance of the FiD, if there is any severe damage (serious dent, components come off, water-stained), please contact the dealer.
- Record the product serial number and shipment date.
- Keep the whole packing material, components and related documents (receipt or invoice) for warranty service.

## 2. Installation

- Shut down the power of the PC and remove the enclosure.
- Set up the jumper settings according to figure 1.

Master : Jumpers off

Slave : Jumpers A to B

Cable select : not support




Figure 1

- Mount the FiD in a drive bay with the screws enclosed in the package
- Connect the ribbon cable (40 or 44 pin connector) to the IDE socket of your system main board.
- Connect the ribbon cable (44 pin connector) to FiD, and make sure to correctly position the pin 1 of the cable to the pin 1 of the FiD.
- Assemble the enclosure and power on the PC.
- Enter the BIOS setting menu and set up the BIOS to recognize the FiD.

### **InnoDisk Corporation**

10F, No. 465, Sec. 6, Zhongxiao E. Rd., Nangang District, Taipei 115, Taiwan, R.O.C.

TEL: +886-2-2653-5565

FAX: +886-2-2653-5965

<http://www.innodisk.com>

E-Mail: [sales@innodisk.com](mailto:sales@innodisk.com)